



### Assembly instruction

Item no. 10000




1 Remove the pole set from the stand.




2 Swivel the two support feet into position.




3 Assemble the pole sections.



4 Attach the pole to the stand.



5 Pull the graphic banner up.



6 Hook the pole to the centre of top rail of the banner.

#### Technical information

##### Graphic material

We recommend a maximum thickness of 0,3 mm / 0.012"

##### Graphic measure

Width: 850 mm / 33.45"  
Printable length: 2020 mm / 79.5"  
Banner length: 2200 mm / 86.5"


##### Facts

Weight: 2,8 kg / 6.2 lbs.  
Total height: 2100 mm / 82.5"  
Carrying bag with shoulder strap included


#### Mounting of graphic banner



1 Open the top rail and position the graphic banner.



2 Lock the top rail.



3 Release the screw and take one of the end caps away.




4 Remove the paper backing from the tape on the leader strip.




5 Attach the bottom of the graphic banner to the leader strip. Back of graphic attaches to the tape.



6 Hold the graphic banner firmly and remove the locking pin.



7 Let the banner slowly roll into the cassette.



8 Reposition the end cap. Fasten with the screw.