

Congratulations on the purchase of your Horizontal Retractor.

Owner's Manual

Includes:

Parts List

Assembly Instructions

Disassembly Instructions

Storage Instructions

Care Instructions

Warranty Information

Please read all of the information carefully and contact your distributor or supplier with any issues.



Parts List

Important: Before you begin please count and inspect all pieces.

- 1- Metal canister with retractable banner (A)
- 1- Carry Case (B)



Assembly Instructions




Step 1

Fold down all of the supports on the base of the metal canister (A).



Step 2

Press in the buttons that are on the front and back of the metal canister (A), and pull the two sections apart.



Step 3

Pull the metal canister (A) sections apart until they are fully extended from each other. Once fully extended press down gently on the mechanism behind the banner to lock into place.

Disassembly Instructions



Step 1

Push the metal canister (A) sections together until it is closed. It should lock in place.



Step 2

Fold up all of the supports on the base of the metal canister (A) by pressing the support foot together.

Storage Instructions



Store in soft carry case (B) in cool, dry place.

Care Instructions

Light spot clean with damp cloth.

Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.